

TC10 Power Take-Off

Overhaul Instructions


Form No.	Issue Date	Rev. Date
T-360	01/19/06	1/9/18

Table of Contents

Introduction	1
General Description	1
Disassembly	1
Propeller Shaft Disconnect and Accessory Removal	1
Eclipse ES CAFSystem Removal from PTO	1
Pump Removal from Transmission	2
Disassembly of PTO	3
Removal End Yokes	3
Coupling Shaft Housing Removal	4
Removing the Bottom Section	4
Removal of the Chain	5
Removal of the Drive Shaft and Housing	5
Removal of Shift Components (Pneumatic, Electric Shift)	6
Removal of Mid-Section from Cap	7
Disassembly of Driven Shaft Assembly	7
Front Facing End Yoke	7
Rear Facing End Yoke	8
Front Facing Hydraulic Pump Provision	8
Rear Facing Hydraulic Pump Provision	9
Front Facing End Yoke/Rear Facing Hydr. Pump Prov.	9
Rear Facing End Yoke/Front Facing Hydr. Pump Prov.	10
Eclipse Mounted CAFS	10
Disassembly of Coupling Shaft Assembly	11
Disassembly of Drive Shaft Assembly	11
Inspection and Repair	12
Reassembly	13
Installing Bearings, Oil Seals and Gaskets	13
Reassembly of the Driven Shaft	13
Front Facing End Yoke	13
Rear Facing End Yoke	14
Front Facing Hydraulic Pump Provision	15
Rear Facing Hydraulic Pump Provision	16
Front Facing End Yoke/Rear Facing Hydr. Pump Prov.	17
Rear Facing End Yoke/Front Facing Hydr. Pump Prov.	18
Eclipse Mounted CAFS	19
Dowel Pins and Spacer Installation	20
Reassembly of the Shift Assembly (Pneumatic or Electric)	21
Reassembly of the Cap and Mid-Section	23
Reassembly of the Drive Shaft and Drive Shaft Housing	24
Installing the Chain	26
Reassembly of the Bottom Section	28
Shift Position Adjustments	29, 30
Coupling Shaft and Housing Assembly	31
Coupling Shaft Housing to Case Assembly	32
Reassembly of Miscellaneous Items and Accessories	33
Eclipse ES CAFSystem Installation onto PTO	34
Propeller Shaft Connection and Accessory Installation	35
Lubrication and Final Checks	35

Illustrations

1. Eclipse ES CAFSystem Removal	2
2. Eclipse ES CAFSystem Air Clutch Assembly (Side View)	2
3. PTO Support	3
4. Removal of End Yokes	3
5. Removal of Coupling Shaft Housing	4
6. Removal of the Bottom Section	4
7. Removable Connecting Pin Set	5
8. Chain Removal	5
9. Removal of Drive Shaft and Housing	5
10. Removal of Shift Components	6
11. Removal of Mid-Section from Cap	7
12. Disassembly of Driven Shaft Assemblies (Figures 12-18)	7
19. Coupling Shaft Disassembly	11
20. Drive Shaft Disassembly - Shift Collar and Oil Seal Removal	11
21. Drive Shaft Disassembly	12
22. Needle Bearing Removal from Sprocket	12
23. Reassembly of the Driven Shaft (Figures 23-29)	13
30. Dowel Pins and Spacer Installation for Extended Drop Cases	20
31. Pivot Pin, Shaft Bushing and Sleeve Bearing Installation	21
32. Shift Arm Assembly	21
33. Shift Assembly (Pneumatic or Electric)	22
34. Mid-Section Assembly	23
35. Cap and Mid-Section Assembly	23
36. Needle Bearing Installation into Drive Sprocket	24
37. Drive Shaft Installation into Drive Sprocket	24
38. Drive Assembly into Drive Housing	25
39. Drive Shaft/Housing Assembly Installation	25
40. Optional Electronic Tachometer	26
41. Installing the Chain	26
42. Connecting Pin Set	27
43. Connecting Pin Orientation	27
44. Assembling Items on the Bottom Section	28
45. Assembling Bottom Section to the Cap and Mid-Section	28
46. Retainer Installation	29
47. Locking Arm Rotation Restrictions	30
48. Coupling Shaft Assembly	31
49. Coupling Shaft Housing Assembly	31
50. Assembling Coupling Shaft Housing to Case	32
51. End Yoke Assembly	33
52. Shift Assembly	33



WATEROUS

Fire Pumps – Since 1886



Waterous Company 125 Hardman Avenue South, South St. Paul, Minnesota 55075 USA (651) 450-5000

Instructions subject to change without notice.

Introduction

This instruction provides the necessary steps required to overhaul the TC10 power take-off. These instructions are divided into Disassembly and Reassembly sections. Also, refer to the Service Parts List (SPL documents) furnished with your TC10 to aid in further part identification and repair parts ordering.

General Description

The Waterous TC10 is a chain driven power take-off with a housing constructed of high-strength aluminum. Drive and driven sprockets are made of hardened steel and have ground bores. Shafts are made of alloy steel forgings, hardened and ground to size. A passive lubrication system

eliminates the need for a separate oil pump. The shift mechanism is a constant-mesh, two-position sliding collar that engages all teeth simultaneously. **Note that the majority of C10 fasteners are metric.**

Disassembly

Before beginning the disassembly process, drain the fluid from the power take-off by removing the drain plug. Note that these instructions apply for out of chassis overhaul of the unit.

Propeller Shaft Disconnect and Accessory Removal

Propeller Shaft Disconnect

Disconnect the propeller shafts.

Electrical Connections

Disconnect the tachometer cable, shift wiring and electric shift override linkage.

Shift Unit

Remove the pneumatic or electric shift unit from the power take-off by removing the two hex nuts and washers. Note that the adjusting screw retaining springs are exposed when the shift unit is removed.

Eclipse ES CAFSystem™ Removal from Power Take-Off (See Figure 1)

To remove the Eclipse ES CAFSystem from the PTO, perform the following steps:

1. Support the Eclipse ES unit with a lifting strap placed under the air compressor. Two other eyeloops are also provided for lifting (see Figure 1).
2. Remove all electrical and air connections.
3. Remove the Polychain cover assembly by unscrewing the ten (10) hex hd screws.
4. Remove the nylon tube from the air clutch assembly.
5. Loosen the 1-29/32" hex screw on the idler sprocket assembly. This releases the idler sprocket assembly for adjustment.
6. Loosen tension on the Polychain by turning the Polychain tension screw, counter clockwise.
7. Remove the Polychain from the air clutch assembly, driven sprocket and idler sprocket.
8. Loosen the set screw that holds the air clutch assembly to the PTO driven shaft. (See Figure 2).
9. Remove the hex head screw that attaches the air clutch assembly to the anti-rotation bracket (leave grommet attached to anti-rotation bracket).
10. Remove the air clutch assembly from the PTO.
11. Remove the five (5) hex hd screws that attach the Eclipse ES unit to transmission.
12. Remove the compressor bracket that supports the Eclipse ES unit to the PTO.
13. Lift the unit off the PTO.

Figure 1. Eclipse ES CAFSystem™ Removal





Figure 2. Eclipse ES - Air Clutch Assembly (Side View)




Disassembly of the TC10

The TC10 consists of three sections; the cap, the mid-section and the bottom section. The order of disassembly is bottom section, mid-section and then cap.

NOTE: Out of chassis overhaul will require supporting the PTO initially in an upside down position, possibly attaching it direct to an engine overhaul stand at the face of the cap (fabrication of an adapter would be required). Another consideration would be to support it on suitable supports on the underside of the flange of the mid-section, first removing the flange bolts at the support areas (see *Figure 3*).


Figure 3. Transmission Supports



Removal of End Yokes

1. Remove the end yokes from the driven, drive and coupling shafts. Do not reuse self-locking nuts. Apply lubricating oil to the threads before moving. Apply anti-seize to the threads before installing a new self-locking nut.
2. Remove the lube system hose.
3. Remove the pneumatic shift.

Figure 4. Removal of Companion Flange and End Yokes




Coupling Shaft Housing Removal

1. Remove the hex head screws and lock washers attaching the coupling shaft housing to the mid-section.
2. Remove the coupling shaft housing, O-ring and shims. Note that jacking screw holes are provided.

NOTE: The coupling shaft and its associated parts may come with the housing. If not, pull on the coupling shaft to remove.


Figure 5. Removal of Coupling Shaft Housing



Removing the Bottom Section

1. Invert the case as shown in Figure 3.
2. Remove lower cap screws connecting the driveshaft housing to the bottom section. Loosen cap screws connecting housing to case mid-section.
3. Remove the cap screws, nuts and lock washers attaching the bottom section to the mid-section.
4. Drive the four dowel pins out of the bottom section flange.
5. Remove the bottom section from the mid-section.

Figure 6. Removal of the Bottom Section




IL2516

Removal of Chain


1. Rotate the drive shaft until removeable connecting pin set of the chain is visible at the drive sprocket. The removable connecting pin set has a spirol pins on both ends holding it in place (see Figure 7).

Figure 7. Removable Connecting Pin Set



2. Remove the tapped in spirol pin on one end, tap both the connecting pin assembly and connecting rocker out of the chain links. Disengage the chain from the drive and driven sprocket and remove from the case.


Figure 8. Chain Removal



Removal of Drive Shaft and Housing

1. Remove the remaining hex head screws and lock washers attaching the drive shaft housing to the mid-section. The housing, drive shaft, drive sprocket, shift collar and associated parts can now be removed as a unit from the mid-section. The shift fork will slip off the shift shaft when the drive shaft assembly is lifted out.

Figure 9. Removal of Drive Shaft and Housing




Removal of Shift Components

1. Remove the shift shoe from the locking arm.
2. Slip locking arm off pivot pin.

NOTE: The pivot pin and shift shaft bushing (typically pressed into the bottom section) need only be removed if bent or otherwise damaged.


3. Remove the shoulder screw that attaches the sector gear and shift lever to the shift shaft and remove the sector gear, shift lever and spacer.
4. Reposition mid and cap section assembly on the supports so that the cap portion is on top or set the assembly on a bench.
5. Remove spirol pin attaching the shift arm to the shift shaft (Figure 10b) if necessary.
6. Remove the shift arm, shift lock spring and shift shaft.

Figure 10a. Removal of Shift Component - (Internal)



IL2232

Figure 10b. Removal of Shift Components (External)




Removal of Mid-Section from Cap

The cap does not need to be removed from the mid-section unless either is being replaced. **NOTE: Removal will make it easier to handle the assembly during driven shaft removal and reassembly.**

1. Remove cap screws and nuts that attach the cap to the mid-section.
2. Remove cap with driven shaft from the mid-section. Rapping the cap with a soft hammer will break adhesion with the shims, spacers and mid-section.

NOTE: Do not drive the dowels through the flange of the cap deeper into the mid-section or spacer plates.

Figure 11. Removal of Mid-Section from Cap




3. Remove any shims and spacers from the top of the mid-section.
 - a. The quantity and thickness of shims and spacers depends on PTO model and ratio.

Disassembly of Driven Shaft Assembly

Front Facing End Yoke

1. Remove the four cap screws that fasten the bearing cover and oil seal housing to the cap. Remove cover and housing. Discard the oil seal.
2. Straighten tab of the bearing lock washer from slot in bearing lock nut and then remove the lock nut, lock washer and wave spring.
3. Under a press, support the assembly on the front face side of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacers and sprockets.
4. Remove the bearing, spacer and sprocket from cap.

Figure 12. Front Facing End Yoke Driven Shaft Disassembly




IL2539

Rear Facing End Yoke

1. Remove the four cap screws that fasten the bearing cover and oil seal housing to the cap. Remove cover and housing. Discard oil seal.
2. Straighten tab of the bearing lock washer from slot in bearing lock nut and then remove the lock nut, lock washer and wave spring.
3. Under a press, support the assembly on the rear face of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacers and sprockets.
4. Remove the bearing, spacer and sprocket from sprocket.

Figure 13. Rear Facing End Yoke Driven Shaft Disassembly




IL2540

Front Facing Hydraulic Pump Provision

1. Remove the four cap screws that fasten the hydraulic pump adapter and bearing cover to the cap. Remove adapter and cover. Discard oil seal.
2. Straighten tab of the bearing lock washer from slot in bearing lock nut and then remove the lock nut, lock washer and wave spring.
3. Under a press, support the assembly on the front face of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacer and sprocket.
4. Remove the bearing, spacer and sprocket from sprocket.

Figure 14. Front Facing Hydraulic Pump Provision Driven Shaft Disassembly




IL2539

Rear Facing Hydraulic Pump Provision

1. Remove the four cap screws that fasten the hydraulic pump adapter and bearing cover to the cap. Remove adapter and cover. Discard oil seal.
2. Straighten tab of the bearing lock washer from slot in bearing lock nut and then remove the lock nut, lock washer and wave spring.
3. Under a press, support the assembly on the rear face of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacer and sprocket.
4. Remove the bearing, spacer and sprocket from cap.

**Figure 15. Rear Facing Hydraulic Pump Provision
Driven Shaft Disassembly**




IL2540

Front Facing End Yoke / Rear Facing Hydraulic Pump Provision

1. Remove the four cap screws that fasten the hydraulic pump adapter and oil seal housing to the cap. Remove adapter and housing. Discard oil seal.
2. Remove the retaining ring and wave spring.
3. Under a press, support the assembly on front face of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacer and sprocket.
4. Remove the bearing, spacer and sprocket.

**Figure 16. Front Facing End Yoke Rear Facing Hydraulic Pump
Provision Driven Shaft Disassembly**




IL2539

Rear Facing End Yoke / Front Facing Hydraulic Pump Provision

1. Remove the four cap screws that fasten the hydraulic pump adapter and oil seal housing to the cap. Remove adapter and housing. Discard oil seal.
2. Remove the retaining ring and wave spring.
3. Under a press, support the assembly on the rear face of the cap and apply a press load to the end of the driven shaft to press the shaft out of the bearing, spacer and sprocket. Rear bearing and retaining ring will come out with the driven shaft. Remove from cap.
4. Remove the bearing, spacer and sprocket from cap.

Figure 17. Rear Facing End Yoke Front Facing Hydraulic Pump Provision Driven Shaft Disassembly




IL2540

Eclipse Mounted CAFS

1. Remove the four cap screws that fasten the bearing cover and oil seal housing to the cap. Remove cover, housing and yoke spacer.
2. Straighten tab of the bearing lock washer from slot in bearing lock nut and then remove the lock nut, lock washer and wave spring.
3. Under a press, support the assembly on the rear side of the case and apply a press load to the end of the driven shaft and press the shaft out of the bearing, spacer and sprocket. Rear bearing and retaining ring will come out with the driven shaft. Remove from shaft.
4. Remove the bearing, spacer and sprocket from cap.

Figure 18. Eclipse Mounted CAFS Driven Shaft Disassembly




IL2616

Disassembly of Coupling Shaft Assembly

1. Press coupling shaft housing off of bearings if not previously removed.
2. Pull outer bearing from the shaft.
3. Remove the spacer and pull inner bearing from the shaft. Note that due to the closeness of the bearing to the hub end of the shaft, a split-plate type puller may be necessary.
4. Tap out pilot bearing if still in coupling shaft by using a punch through the two access holes in the coupling shaft.

Figure 19. Coupling Shaft Disassembly




Disassembly of Drive Shaft Assembly

1. Slide shift collar from teeth on the drive shaft.

NOTE: If the transmission is equipped with an electronic tachometer, remove the pick-up from the housing prior to removal of the drive-shaft housing to avoid damage.

2. Press drive shaft housing from drive shaft assembly and press the oil seal from housing. Discard the oil seal.
3. Remove the tachometer pulse generator (if equipped) with a suitable puller (see Figure 21).


Figure 20. Drive Shaft Disassembly - Shift Collar Removal and Oil Seal



Disassembly of Drive Shaft Assembly Cont'd


4. Remove spacer if applicable.
5. Place shaft and sprocket assembly in an arbor press in a vertical position with the threaded end up and supported on the bottom face of the sprocket. Press shaft out of drive sprocket assembly. Catch shaft to avoid damage.
6. Remove needle bearings from the sprocket.

Figure 21. Drive Shaft Disassembly



IL2529

Figure 22. Needle Bearing Removal from Sprocket



IL2526

Inspection and Repair

Check the following:

- ❑ Bent shift forks
- ❑ Bent shift shaft
- ❑ Worn shifter shoes
- ❑ Loose shifter shoe studs
- ❑ Damaged locking arm assembly, sector gear or bent pivot pin
- ❑ Condition of oil hose
- ❑ Worn sprocket teeth
- ❑ Worn flanks on inner chain links
- ❑ Outside guide links of chain not retained by "driveted over" pins
- ❑ Wear on inner faces of outside guide links of chain
- ❑ Badly worn pointing on teeth of drive sprocket, coupling shaft and shift collar
- ❑ Damaged splines on drive and coupling shafts

Before reassembly, make sure all reusable parts have been cleaned and are kept free of dirt during reassembly.

Reassembly

Guidelines for Installing Bearings, Oil Seals, O-Rings and Hardware

Installing Bearings

Keep new bearings wrapped until they are to be installed. When pressing the bearing on a shaft or into a bore, coat appropriate surfaces with grease.

Shaft - grease shaft and bearing bore.

Bore - grease bore and outside of diameter of bearing.

Always apply force to the inner race of a bearing when pressing it on a shaft and to the outer race if pressing into a bore. Press evenly with a piece of pipe or tube which just clears the shaft.

NOTE: Wherever silicone or sealant is referenced, use Loctite Ultra Blue RTV Silicone Sealant or equivalent, unless otherwise specified.

Installing Oil Seals

Before installing an oil seal in its housing, apply a thin coat of sealant to housing oil seal seat. Be sure that the seal, shaft and housing are clean. Always install a seal with the seal lip facing in. Lubricate seal lip with light oil before installing shaft. Apply force to the outer edge of the seal and press in evenly.

Installing O-Rings

Grease O-rings prior to installation. This will aid in the installation as well as preventing damage to the O-ring.

Installing Hardware


Torque specifications for screws: M10 36-40 lb-ft.
M12 64-69 lb-ft.

Reassembly of the Driven Shaft

Front Facing End Yoke

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the shoulder on the yoke end of the driven shaft.
3. Tap the key into place.
4. Place high pressure grease in the rear bore of the cap.
5. Tap the bearing into place.
6. Set the bearing cover on rear face of cap and secure with the hex head screw and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on the rear face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the front face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the oil seal housing.
11. Install oil seal housing.
12. Tap lock nut end of driven shaft towards oil seal housing to seat assembly.
13. Remove the bearing cover and install the O-ring, bearing lock washer and lock nut. Make sure the tang of the washer aligns with the keyway in the shaft.
14. Tighten nut 1/4 turn from finger tight and bend one of the locking tangs on the washer into one of the slots in the locknut.
15. Install wave spring and bearing cover.

Figure 23. Front Facing End Yoke Reassembly of the Driven Shaft




IL2541

Rear Facing End Yoke

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the shoulder on the yoke end of the driven shaft.
3. Tap the key into place.
4. Place high pressure grease in the front bore of the cap.
5. Tap the bearing into place.
6. Set the bearing cover in cap and secure with the hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on the front face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the rear face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the oil seal housing.
11. Install the oil seal housing.
12. Tap lock nut end of driven shaft towards oil seal housing to seat assembly.
13. Remove the bearing cover and install the O-ring, bearing lock washer and lock nut. Make sure the tang of the washer aligns with the keyway in the shaft.
14. Tighten nut 1/4 turn from finger tight and bend one of the locking tangs on the washer into one of the slots in the locknut.
15. Install wave spring and bearing cover.

Figure 24. Rear Facing End Yoke Reassembly of the Driven Shaft




IL2542

Front Facing Hydraulic Pump Provision

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the shoulder on the internal spline end of driven shaft.
3. Tap the key into place.
4. Place high pressure grease in the rear bore of the cap.
5. Tap the bearing into place.
6. Set the bearing cover in the cap and secure with hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on its rear face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the front side of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the hydraulic pump adapter.
11. Install the hydraulic pump adapter.
12. Tap lock nut end of driven shaft towards oil seal housing to seat assembly.
13. Remove the bearing cover and install the bearing lock washer and lock nut. Make sure the tang of the washer aligns with the keyway in the shaft.
14. Tighten nut 1/4 turn from finger tight and bend one of the locking tangs on the washer into one of the slots in the locknut.
15. Install wave spring and bearing cover.

Figure 25. Front Facing Hydraulic Pump Provision Reassembly of the Driven Shaft




IL2541

Rear Facing Hydraulic Pump Provision

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the should on the internal spline end of the drive shaft.
3. Tap the key into place.
4. Place high pressure grease in the front bore of the cap.
5. Tap the bearing into place.
6. Set the bearing cover on cap and secure with hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on its front face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the rear face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the hydraulic pump adapter.
11. Install the hydraulic pump adapter.
12. Tap lock nut end of driven shaft towards oil seal housing to seat assembly.
13. Remove the bearing cover and install the bearing lock washer and lock nut. Make sure the tang of the washer aligns with the keyway in the shaft.
14. Tighten nut 1/4 turn from finger tight and bend one of the locking tangs on the washer into one of the slots in the locknut.
15. Install wave spring and bearing cover.

Figure 26. Rear Facing Hydraulic Pump Provision Reassembly of the Driven Shaft




IL2542

Front Facing End Yoke Rear Facing Hydraulic Pump Provision

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the shoulder on splined end of driven shaft.
3. Tap the key into place.
4. Place high pressure grease in the rear bore of the cap.
5. Tap the bearing into place.
6. Set the hydraulic pump adapter on cap and secure with hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on its rear face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the front face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the oil seal housing.
11. Install the oil seal housing.
12. Remove the hydraulic pump adapter and install retaining ring.
13. Tap internal splined end of driven shaft towards front face to seat assembly.
14. Install O-ring and oil seal in hydraulic pump adapter.
15. Install wave spring and hydraulic pump adapter.

**Figure 27. Front Facing End Yoke
Rear Facing Hydraulic Pump Provision Reassembly of the Driven Shaft**




IL2541

Rear Facing End Yoke Front Facing Hydraulic Pump Provision

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing to the shoulder on the external splined end of the driven shaft.
3. Tap the key into place.
4. Place high pressure grease in the front bore of the cap.
5. Tap the bearing into place.
6. Set the hydraulic pump adapter on the front face of the cap and secure with hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on the front face, position spacer and the driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the rear face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install O-ring and oil seal in the oil seal housing.
11. Install the oil seal housing.
12. Remove the hydraulic pump adapter and install the retaining ring.
13. Tap internal spline end of driven shaft towards rear face to seat assembly.
14. Install O-ring and oil seal in hydraulic adapter.
15. Install wave spring and hydraulic pump adapter.

**Figure 28. Rear Facing End Yoke
Front Facing Hydraulic Pump Provision Reassembly of the Driven Shaft**




IL2542

Eclipse ES Mounted CAFS

1. Use high pressure grease to coat the driven shaft.
2. Press the bearing (1) onto the shaft and secure in place with retaining ring.
3. Tap the key for the driven sprocket into place.
4. Place high pressure grease in the front bore of the cap.
5. Tap the bearing (2) into place.
6. Set the bearing cover on cap and secure with hex head screws and lock washers. Hand tighten only at this stage of reassembly.
7. With the cap resting on the front face, position the spacer and driven sprocket inside the cap.
8. Take the driven shaft, bearing and key assembled previously and from the rear face of the cap, slide the shaft through the bore in the cap into the bore of the driven sprocket, spacer and ball bearing lining up the key in the shaft with the keyway in the sprocket.
9. Tap into place until the shaft seats.
10. Install the oil seal in the oil seal housing.
11. Install the shim and oil seal housing.
12. Tap lock nut end of driven shaft towards oil seal housing to seat assembly.
13. Remove the bearing cover and install the O-ring, bearing lock washer and lock nut. Make sure the tang of the washer aligns with the keyway in the shaft.
14. Tighten nut 1/4 turn from finger tight and bend one of the locking tangs on the washer into one of the slots in the locknut.
15. Install wave spring and bearing cover.

**Figure 29. Eclipse ES Mounted CAFS
Reassembly of the Driven Shaft**




IL2617

Dowel Pins and Spacer Installation (Extended Drop Chain Cases)

1. Place high pressure grease on the dowel pin holes and install into the cap.
2. Apply a thin film of silicone inside bolt hole pattern and outside the oil port hole as shown in Figure 30.
3. If shims are required, apply bead of silicone inside bolt pattern on spacer, then lay shims on the spacer.
4. Position cap on spacer and tap dowel pins into place.
5. Secure with appropriated hardware (see Service Parts List SPL82747 - TC10 or SPL82821 - TC10 Eclipse ES).

Figure 30. Dowel Pins and Spacer Installation (for Extended Drop Chain Cases - C, D & E Drop)




Reassembly of the Shift Assembly

1. File and clean sealing surfaces of the mid-section and clean out any metal chips or shavings.
2. Apply a small amount of grease to the O-ring and install on the groove of the pivot pin. Apply Loctite #242 to the pivot pin per Figure 31 and install into the mid-section.

NOTE: Avoid getting Loctite #242 on O-ring surface.

3. Install the sleeve bushing 1/2" down into the shift shaft bore. Apply silicone sealant to the outside diameter of the flange bearing and then install it into the shift shaft bore. Make sure there is a 1/8" gap between the bushing and bearing.
4. Apply a small amount of grease on the O-ring and install between the bushing and bearing.
5. Install spirol pin in mid-section.
6. Install the spring housing into the spirol pin.

Figure 31. Pivot Pin, Shaft Bushing and Sleeve Bearing Installation



Shift Assembly

1. Invert mid-section.
2. Attach shift arm to shift shaft with spirol pin (see Figure 32).
3. Install shift lock spirol pin in shift arm.
4. Grease the shift shaft.

Figure 32. Shift Arm Assembly





Figure 33. Shift Assembly



5. Slide the shift lever into the sector gear aligning the holes (see Figure 33).
 6. Set shift lever/sector gear over the shift shaft opening in the mid-section.
 7. Slide shift shaft up through the shift shaft opening, engaging spacer and shift lever or shift lever/sector gear.
 8. Install the shift lock spring into the spring housing (see Figure 32).
 9. Engage shift arm spirol pin with the shift lock spring (see Figure 32).
 10. Rotate the shift arm to compress the shift lock spring into the housing. Line up the holes in the shift lever/sector gear and install shoulder screw and locking nut.
 11. Install the locking arm onto the pivot pin (see Figure 33) and mesh the teeth with the sector gear. Proper alignment is important. The center tooth space in the sector gear should be centered with the locking arm.
 12. Install the shift shoe assembly on the pin of the locking arm.
- NOTE: Shift shoe can be installed with the counter bore either up or down.**
- NOTE: Shift mechanism may not shift smoothly until bottom cover is installed.**
13. Install adjusting screws in the mid-section and adjust so the locking arm is rotatable slightly less than 90° each direction (see Figure 33).
 14. Install screw retainers. Place a dab of grease on the retainers to hold them in place until the shift unit or cover can be installed.
 15. Check assembly for proper shifting.

Reassembly of the Cap and Mid-Section

1. Make sure the face of the mid-section is clean and free of nicks and burrs.
2. Clean shims or spacer. If assembly includes a spacer, grease dowel pin holes in mid-section and install dowel pins. If no spacer is required, grease dowel pin holes in cap and install dowel pins.
3. Apply a thin film of silicone inside bolt hole pattern and outside the oil port hole as shown in Figure 34.
4. If no spacer is being used and shims are required, install shims on the mid-section. Apply a bead of silicone inside the bolt hole pattern on top of shims.
5. Install cap or cap and spacer to mid-section.
 - a. Cap only: Position cap on mid-section and tap dowel pins into mid-section.
 - b. Cap with spacer: Position cap assembly on the dowels previously installed in the mid-section and tap down into place.
6. Install appropriate hardware.
7. Support the mid-section and cap assembly in an upside down position on suitable supports (see Figure 3).

Figure 34. Mid-Section Assembly





Figure 35. Cap and Mid-Section Assembly




Reassembly of the Drive Shaft and Drive Shaft Housing

Drive Shaft Assembly

1. File and clean the sprocket faces and check teeth for burrs.
2. Use high pressure grease in the bore of the drive sprocket.
3. Press the needle bearings into each end of the bore of the drive sprocket. Press rounded end of bearing into sprocket bore. Bearings should set just below the slots in the sprocket.

Figure 36. Needle Bearing Installation into Drive Sprocket




IL2526

4. Install pilot bearing on end of drive shaft.
5. Use high pressure grease on the drive shaft and press into the drive sprocket assembly.
6. Check the shift collar (not shown) for proper fit. Do not install at this time.

7. Install the thrust washer onto the drive shaft.
8. Apply grease and install the ball bearing.
9. If the tachometer option is used, add the tach pulse generator and spacer required. If no tach is required, install appropriate spacer.

NOTE: Drive sprocket assembly should turn freely.

Figure 37. Drive Shaft Installation into Drive Sprocket




IL2529

Drive Shaft Housing Assembly

1. Apply a light coat of silicone to the housing bore and install the oil seal.
2. Apply grease to the O-ring and insert into the housing.
3. Use high pressure grease in the bore of the housing and press the housing onto the drive shaft assembly.
4. Add the shift collar onto the drive line.
5. Check the shift fork shoes for free movement.
6. Slide the shift fork onto the shift collar.


Figure 38. Drive Assembly into Drive Housing



Drive Shaft/Housing Assembly Installation

1. Apply grease to stud on the shift shoes for temporary installation. Then, install the drive shaft assembly into the mid-section and onto the shift shaft. Make sure the shift shoe on the locking arm is mated with the slot in the fork. The drive shaft housing should be seated.
2. Install hex head screws and lock washers to secure the drive housing to the mid-section. Do not completely tighten. Leave a small gap between the drive shaft housing and mid-section flange to allow installation of the bottom cover.


Figure 39. Drive Shaft/Housing Assembly Installation



Optional Electronic Tachometer

1. Install the O-ring onto the tachometer pick-up.
2. Rotate drive shaft until tach tooth lines up with the tach opening.
3. Install the tachometer pick-up into the drive shaft housing until it contacts the tach pulse generator. Turn back 1/2 turn.
4. Tighten hex nut.

Figure 40. Optional Electronic Tachometer




IL2530

Installing the Chain

1. Wrap the chain around the drive and driven sprockets making sure everything meshes and then lace the joining ends together using the connecting pin set (see Figure 41).
2. Insert the connecting pin rocker partway through the holes in the joining end links being careful of orientation (see Figure 43). The connecting rocker must be on the side of the guide link opposite the joining end with the connecting rockers wide curved surface towards the center of the hole.
3. Insert the connecting pin assembly along side the connecting rocker. The two wide curved surfaces of the connecting pin and connecting rocker must face each other.
4. After the connecting pin assembly and connecting rocker have been pushed all the way through the joining ends of the chain, insert the spirol pin into the open hole at the end of the connecting pin assembly (see Figure 43). Make sure the spirol pin overlaps the connecting rocker.
5. Check chain for proper tension. Check deflection half-way between the drive sprocket and driven sprocket (see chart below for maximum deflection). Replace chain if deflection is greater than those displayed in the chart below.

Figure 41. Installing the Chain



IL2431

Drop	Max Deflection (In.) (Both Directions)
B	1.75
C	1.75
D	1.75
E	2.0
F	2.0

Figure 42. Connecting Pin Set





Figure 1. Connecting Pin Set

The connecting pin set contains one connecting pin assembly, one connecting rocker and one spirol pin.


Figure 43. Connecting Pin Orientation



Reassembly of the Bottom Section to the Cap and Mid-Section

1. Apply Loctite #242 to the shift shaft bushing and install into the bottom of the case.
2. Apply pipe joint compound to the sight plug.
3. Install the sight and magnetic plugs in the case.


Figure 44. Assembling Items on the Bottom Section



IL2536

4. Tap back the drive shaft assembly to allow for the bottom section installation.
5. Apply silicone around the inside of the bolt hole pattern as shown in Figure 45.
6. Install the bottom section onto the mid-section. Be sure to engage the shift shaft with shift shaft bushing.
7. Install four dowel pins into place.
8. Secure the bottom section to the mid-section with fasteners.

Figure 45. Assembling Bottom Section to the Cap and Mid-Section




IL2516

Shift Position Adjustments


1. Check the distance from shift collar to face of coupling shaft housing bore. Distances should read as follows:
 - ▣ ROAD mode: 1-3/8 inches (right adjusting screw)
 - ▣ PUMP mode: 2-11/16 inches (left adjusting screw)
 - ▣ Note: Locking arm must not rotate beyond 90° from center position to avoid disengagement of shift shoe. See Figure 47 on next page.
2. Adjust as necessary.
3. Install retainers. Apply grease into the slots to help secure retainers.

Figure 46. Retainer Installation



Shift Position Adjustments (Continued)

Figure 47. Locking Arm Rotation Restrictions




Coupling Shaft and Housing Assembly

Coupling Shaft Assembly

1. Use high pressure grease and press bearing, spacer and bearing onto shaft.

Figure 48. Coupling Shaft Assembly




IL2527

Coupling Shaft Housing Assembly

1. Coat the seal outer diameter evenly with sealant. Be sure that the seal, shaft and housing are clean. Always install a seal with the seal lip facing in. Apply force to the outer edge of the seal and press in evenly.
2. Use high pressure grease in bore of the coupling housing and press coupling shaft assembly into place.

Figure 49. Coupling Shaft Housing Assembly



IL2528

Coupling Shaft Housing Assembly to Case Assembly

The driveline assembly was factory shimmed to limit the axial float of the drive line. If any of the drive line parts have been changed, it may be necessary to change the total thickness of shims between the coupling shaft housing and the transmission case. Shims are color coded for thickness as follows:

- .005" Blue
- .007" Natural
- .010" Brown


The correct thickness of shims can be determined as follows:

1. Install coupling shaft and housing assembly with no O-ring or shims between the housing and case. Lightly tighten the cap screws evenly and tap the end of the coupling shaft with a soft mallet to force the drive line all the way forward. Do not overtighten causing bending or breakage of the coupling shaft housing.
2. Measure the gap between the housing and case in several places to assure a uniform gap and add .005 in. This will be the total thickness of shims needed to provide the recommended axial float of .005 - .010 in.
3. Remove the coupling shaft assembly from the case after measuring the gap.

NOTE: Field conditions may make it difficult to determine the correct amount of shims. If in doubt, add another .005 in. shims. No harm will result from a small amount of additional axial float but bearing life will be shortened if bearings are excessively preloaded.

4. Install the correct amount of shims on the coupling shaft housing or if all original parts are being used, reinstall original shims on coupling shaft housing.
5. Coat O-ring with grease and install O-ring on housing.
6. Install the coupling shaft housing assembly.
7. Install fasteners.

Figure 50. Assembling Coupling Shaft Housing to Case



Breather and Hose Assembly Installation


1. Apply thread sealer to breather and install.
2. Connect hose assembly from the cap to the mid-section.

Reassembly of Miscellaneous Items and Accessories

End Yoke Assembly

1. Slide yoke onto the coupling shaft and drive shafts.
2. Secure in place using washers and self-locking nuts. Anti-seize should be applied to the threads before installing a self-locking nut. Do not reuse self-locking nuts. Torque to 475-525 lb-ft.
3. Slide yoke on the output shaft.
4. Secure in place using a self-locking nut. Anti-seize should be applied to the threads before installing a self-locking nut. Do not reuse self-locking nuts. Torque to 275-325 lb-ft.


Figure 51. End Yoke Assembly



Shift Accessory Assembly

1. Attach the switch to the switch bracket using a seal and locking nut. Install the cap.
2. Set the gasket on the mid-section.
3. Align the shift arm with the piston in the shift unit and install bracket, gasket and shift unit to the case with lock washers and hex nuts. Note that the word "TOP" cast into the shift unit.
4. Test the shift operations as required.

Figure 52. Pneumatic Shift Assembly



Eclipse ES CAFSystem™ Installation onto PTO (See Figure 1)

To install the Eclipse ES CAFSystem onto the TC10, perform the following steps:

1. Support the Eclipse ES unit with a lifting strap placed under the air compressor. Two other eyeloops are provided for lifting (see Figure 1).
2. Lift the unit onto the TC10.
3. Install the compressor bracket that supports the Eclipse ES unit to the TC10.
4. Install the five (5) hex hd screws that attach the Eclipse ES unit to the TC10.

NOTE: Apply anti-seize to shaft before installing air clutch.

5. Apply Loctite 609 to keyway, install key and align clutch assembly. Push assembly into place.

NOTE: Locate clutch assembly to ensure proper interface between set screw and its seating hole.

6. Lock air clutch assembly into place for final polychain adjustment using set screw (use Loctite 242).

7. Install the hex hd screw that attaches the air clutch assembly to the anti-rotation bracket).
8. Install the Polychain onto the air clutch assembly, driven sprocket and idler sprocket.
9. Connect the nylon tube to the air clutch assembly.
10. Tighten Polychain until taught using the Polychain tensioning screw. Polychain tension may be checked by applying a 10 lb. load to the Polychain, mid-span between drive and driven sprocket. The Polychain should deflect .250 to .313".
11. Tighten the large hex head screw on the idler sprocket.
12. Reconnect all electrical and air connections.
13. See Lubrication and Final Checks section for final polychain adjustment.

Propeller Shaft Connection and Accessory Installation

Electrical Connections

Connect the tachometer cable, electric shift wiring and primer motor wiring as required.

Primer

Connect the priming pump and hose to the priming pump.

Pneumatic Shift

- ▣ Connect power supply and truck transmission interfaces.
- ▣ SAE J1402 air brake hose recommended, 1/4" to 3/8". Connect air lines from main truck supply.

Drain Valve

Connect the manifold drain valve.

Propeller Shaft

Connect the propeller shafts to the drive and coupling shafts

Lubrication and Final Checks

1. Fill the transmission through the fluid level hole or by removing the breather and adding fluid through this opening. Any type of automatic transmission fluid (ATF) can be used. Capacity is approximately 12 quarts (fill to the bottom of threads of the oil level port).
2. Recheck fasteners for tightness.
3. Check for oil leaks.
4. Recheck for proper operation of shift mechanism and that the shift indicator light system is functioning properly.

Eclipse ES Units Only

5. Engage water pump and CAFS per appropriate operating instructions. Operate system for ten (10) minutes.
6. Check Polychain tension. Apply a 10 lb. load to the Polychain, mid-span between drive and driven sprocket. The Polychain should deflect .250 to .313. Adjust tension with Polychain tensioning screw. When tension is correct, loosen large hex head screw on the idler sprocket and apply a bead of Loctite 243 Blue to the threads. Tighten hex head screw.
7. Install the Polychain cover.