Form Number: F-2997



Fire Troll Foam Proportioner

Installation, Operation, and Maintenance




Table of Contents

Safety	4
Safety Precautions	4
Introduction	5
Using this Document	
Viewing the Document Electronically	
Printing the Document	5
Additional Documentation	
Symbols	
Product Overview	6
Fire Troll Proportioner Overview	
Eductor Body with Control Handle and Fittings	
Concentrate Supply Hose	
Foam Selector Plate	
Installation	10
Installation Overview	10
Optional Equipment	
Preparing for the Installation	
Eductor Dimensions	
Panel Plate Cutout Dimensions	
Alternative Installation Valve Assembly Cutout Dimensions	
Drilling the Mounting Holes	
Mounting the Eductor to the Panel	
Installing the Valve Assembly	
Installing the Panel Plate	
Installing the Hose Assembly	
Alternative Installation—Mounting the Valve Assembly Alternative Installation—Connecting the Valve Assembly to Eductor	
Operation	21
Connecting the Concentrate Supply	
Adjusting the Solution	
Performance Table	23
Maintenance	24
Flushing the System	24
Clearing a Check Valve Jam	

SAFETY

Safety Precautions

- Read and understand all the associated documentation before you begin the installation.
- Read and understand all the notices and safety precautions.
- Be aware that these instructions are only guidelines and are not meant to be definitive. Contact Waterous when you have questions about installing, operating, or maintaining the equipment.
- Do not install the equipment if you are not familiar with the tools and skills needed to safely perform the required procedures—proper installation is the responsibility of the purchaser.
- Do not operate the equipment when safety guards are removed.
- Do not modify the equipment.
- Regularly check for leaks, worn, or deteriorated parts.

NOTICE

Before Operation

- Read and understand all the instructions provided.
- Check all fluid levels and replenish if necessary.
- Remove all shipping plugs and install the operation plugs or caps.



NOTICE

Freeze Damage •Do not allow fluid in the lines to freeze.

•Remove all freezable fluid from the lines before storing the apparatus. SAFETY

Use this document to install and operate your Waterous equipment. Understand the following conditions before continuing with the document:

- The instructions may refer to options or equipment that you may not have purchased with your system.
- The illustrations in this document are intended to convey concepts. Do not use the illustrations to determine physical attributes, placement, or proportion.
- Understand that your application may require additional steps, that are not described in the illustrations or instructions, to perform the installation.
- Any equipment described in this document is intended to be installed by a person or persons with the necessary skills and knowledge to perform the installation.
- Any equipment described in this document is intended to be operated by a
 person or persons with the basic knowledge of operating similar equipment.
- Do not install the equipment if you are not familiar with the tools and skills needed to safely perform required procedures—proper installation is the responsibility of the purchaser.

This document is divided into the following sections:

SAFETY

This section describes general precautions and alert symbols that are in this document.

INTRODUCTION

This section is an overview of the document.

PRODUCT OVERVIEW

This section describes the components that make-up the system.

INSTALLATION

This section describes the installation and initial setup procedures.

OPERATION

This section describes the equipment operation.

MAINTENANCE

This section describes maintaining the equipment.

Using this Document

Use the guidelines below when viewing this document.

Viewing the Document Electronically

- · View this document in landscape orientation.
- Use the table of contents to navigate directly to that section.
- Text with this appearance is linked to a reference.

Printing the Document

- The document is viewed the best when printed in color.
- The *print on both sides* and *flip on long edge* features can provide the best results.
- Use a 3-ring binder to store the document.

Additional Documentation

Additional documentation is available through the MyWaterous login at Waterousco.com. Use your serial number to gain access to the service parts list associated with your system. Dimensional drawings are available through the Waterous Service department.

Symbols

Symbols are used to illustrate additional tools or operations that are required to complete the instructions.



, Drill—This symbol tells you to drill holes in the apparatus.



Jig saw—This symbol tells you to make a cutout in the apparatus.

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
--------	--------------	------------------	--------------	-----------	-------------


Fire Troll Proportioner Overview

1

3

4


The Fire Troll concentrate proportioning system passively injects concentrate into a solution capable discharge. You can manually adjust the amount from no injection to just under 1%. The Fire Troll can be installed on the apparatus within typical discharge pluming, just before a hose real, or inserted in a hose-lay. It is compatible with a wide range of nozzles-6 to 125 gpm.



SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE

Eductor Body with Control Handle and Fittings

The eductor body is a molded encasement containing the internal components.



	Feature	Description
1	Eductor body	This encapsulates the eductor components.
2	Guide holes	This allows you to drill mounting holes and mount the eductor to the apparatus.
3	Inlet	This is the inlet for clear water—1-1/2 NPT.
4	Outlet	This is the outlet for clear water or solution—1-1/2 NPT.
5	Concentrate inlet	This connects to the concentrate supply.
6	Valve assembly	This allows you to adjust the amount of ejected concentrate.


SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
Concentrate	e Supply Hose				
	oncentrate supply.				
	1				
	2			3	
		Ň		4	

	Feature	Description
1	Check valve	This prevents contamination of concentrate by preventing reverse fluid flow in the line.
2	Supply hose connection	This connects to the eductor.
3	Supply hose	This transfers the concentrate to the eductor.
4	Foam pail capper	This connects to the concentrate supply pail.

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	Installation	OPERATION	MAINTENANCE

Foam Selector Plate

This mounts to the valve assembly and indicates the relative amount of concentrate injected during operation.



	Feature	Description
1	Panel mounting holes	This mounts to the operator panel.
2	Scale indicator	This indicates the relative amount of concentrate injecting during operation.
3	Eductor mounting holes	This mounts to the valve assembly.

Installation Overview

This equipment is intended to be installed by a person or persons with the basic knowledge of installing similar equipment. Contact Waterous with questions about installing the equipment. The installation may require the following tasks and abilities:

- Locating, drilling, and cutting features into the apparatus
- Connecting to pluming
- Final testing.
- Do not install the equipment if you are not familiar with the tools and skills needed to safely perform required procedures—proper installation is the responsibility of the purchaser.

Optional Equipment

Be aware that the installation instruction may include optional equipment not included in your application.

Preparing for the Installation

Read and understand all the installation instructions before installing the equipment. Prepare a suitable, well-lit area, and gather all the necessary tools before you begin the installation.



Before Operation


- Read and understand all the instructions provided.
- Check all fluid levels and replenish if necessary.
- Remove all shipping plugs and install the operation plugs or caps.



SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE

Eductor Dimensions


Use the illustration to create the cutout and drill the mounting holes for the eductor.



SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
--------	--------------	-------------------------	--------------	-----------	-------------

Panel Plate Cutout Dimensions


Use the illustration to create the cutout and drill the mounting holes for the panel plate.




SAFETY INTRODUCTION PRODUCT OVERVIEW IN	TALLATION OPERATION MAINTENANCE
---	---------------------------------

Alternative Installation Valve Assembly Cutout Dimensions

Use the illustration to create the cutout and drill the mounting holes for the alternative installation.



SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
Drilling the	Mounting Holes				
.				Use the illustration and cutout and mounting ho	instructions to create the les for the eductor.
L					to drill the mounting holes
				Note: Pilot holes an	e featured on the eductor licate where you can safely nting holes.
		Burnage			
	°				




SAFETY	INTRODUCTION	PRODUCT OVERVIEW	Installation	OPERATION	MAINTENANCE
nstalling th	e Valve Assembly				
				Use the illustration and i valve assembly.	nstructions to install the
				1 Install the valve ass eductor.	embly to the fitting on the
	Co Frances				

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	Installation	OPERATION	MAINTENANCE
Installing th	e Panel Plate				
				Use the illustration and panel plate to the valve	
				1 Locally source the a mount the panel pla	appropriate hardware to te to the valve assembly.
	۲)		

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE	
Installing th	e Hose Assembly					
				hose assembly.	Use the illustration and instructions to mount the hose assembly.	
				1 Install the hose ass	embly to the valve assembly.	
	/					
	0					
	Ø					

Alternative Installation—Mounting the Valve Assembly




Use the illustration and instructions to remotely mount the eductor and panel mount the valve assembly.

- 1 Create the cutout and drill the mounting holes for the eductor. Refer to: "Alternative Installation Valve Assembly Cutout Dimensions" on page 13.
- 2 Locally source the appropriate hardware to mount the valve assembly and the panel plate to the operator panel.

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	Maintenance
Iternative I	Installation—Conne	ecting the Valve Assembl	y to Eductor		
					nstructions to remote mount t it to the valve assembly.
				1 Locally source the a mount the eductor b	ppropriate hardware to ody.
					ppropriate hose to connect
		i.			
		2			

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
onnecting	the Concentrate Su	upply			
	٠			Use the illustration and i	nstruction to connect the
	_			1 Insert the wand into tighten the capper.	the concentrate supply and
	•				
		1			



SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE

Performance Table


Inlet Pressure—PSI	Water Flow—GPM	Concentrate Flow—GPM**	% Foam
	35	0.347	0.99
100	50	0.375	0.75
	100	0.350	0.35
	35	0.350	1.00
125	50	0.350	0.70
	100	0.350	0.35
150	50	0.250	0.50
150	100	0.300	0.30

Values based on factory conditions. Pressure drop across Fire Troll is 30-60 PSI depending on flow. **Foam concentrate metering valve fully open.

SAFETY	INTRODUCTION	PRODUCT OVERVIEW	INSTALLATION	OPERATION	MAINTENANCE
lushing the	e System				
					ach use to prevent any ld degrade performance. ter to prevent freezing whe
				1 Insert the wand into	
	•			2 Set the handle to ma flowing the waterwa	
				NO	TICE
			Ē	Freeze Damag •Do not allow fluid in lines to freeze.	the O
				 Remove all freezable from the lines before storing the apparatus 	W V W V

1

Clearing a Check Valve Jam



Use the illustration and instructions to clear a check valve jam condition if a jam condition occurs.

1 Use a wooden dowel to relieve the spring pressure to dislodge any trapped debris from the seal around the check valve .

WATEROUS

Waterous Company 125 Hardman Avenue South South Saint Paul, MN 55075 (651) 450-5000 www.waterousco.com